

CLEANING INSTRUCTIONS

Regular Cleaning:

- For everyday cleaning, wipe the surface with a damp cloth or sponge. You may use a mild soap or detergent. Wipe completely dry with a soft rag using a straight line motion.
- Wilsonart® laminate may need occasional dusting depending on where it is used. To keep the surface beautiful, use a non-oily furniture spray. (Remember to clean the spray off several times a year to prevent buildup.)
- Furniture polish can also help to hide fine scratches in the surface. Be sure to completely wipe the polish from the laminate surface. The oils in the polish cannot penetrate the laminate and any residual polish could subject the users hands and clothing to stains.

Stains:

- Difficult stains such as coffee or tea can be removed using a mild soap or detergent and a soft bristled brush. Repeat as necessary.
- If a stain persists, use a paste of baking soda and water applied with a soft bristle brush. Light scrubbing for 10 to 20 strokes should remove most stains. Although baking soda is a low abrasive, excessive scrubbing or exerting too much force could damage the decorative surface, especially if it has a gloss finish.
- Stubborn stains that resist any of the above cleaning methods may require the use of undiluted household bleach or nail polish remover. Apply the bleach or nail polish remover to the stain and let stand no longer than two minutes. Rinse thoroughly with warm water and wipe dry. This step may be repeated if the stain appears to be going away and the color of the laminate has not been affected.
WARNING: Prolonged exposure of the laminate surface with bleach will cause discoloration.
- ***Always rinse laminate surfaces after cleaning!*** If a small amount of cleaning solution remains on the surface, moisture can reactivate it and result in permanently etched scars.

RECOMMENDED CLEANING AGENTS

Wilsonart Recommends:

- Clorox®
- Formula 409®
- Dawn®
- Dow® Bathroom Cleaner with Scrubbing Bubbles
- Fantastik®
- Favor®
- Pledge®
- Windex®
- Lestoil®
- Glass Plus®
- Grease Relief®
- Lysol® Brand Disinfectant Basin/Tub/Tile Cleaner
- Mr. Clean®
- Top Job®

SPECIAL CARE TIPS

- Keep your furniture out of direct sunlight. Prolonged exposure may cause the color to fade over time. Wilsonart® laminates will maintain their normal coloration in indoor use within acceptable limits established by NEMA LD3-2000.
- Hot pans or heat producing appliances, when set directly on the laminate, can mar the product's surface. Always use a heat shield, hot pad, or trivet.
- Sharp knives can damage the surface of the laminate lowering the wear and stain resistance of the surface. Always use a cutting board if cutting directly on the surface.
- Acidic or abrasive cleaners can damage laminate surfaces, do not use them to clean the surface. ***Avoid products that contain any of the following:***
 - Hydrochloric Acid
 - Muriatic Acid
 - Hydrogen Chloride
 - Sulfuric Acid
 - Oleic Acid
 - Oil of Vitriol
 - Oleum
 - Hydrofluoric Acid
 - Rust Remover
 - Phosphoric Acid
 - Rust remover
 - Sodium Hydroxide
 - Caustic Soda
 - Caustic
 - Lye
 - Soda Lye
 - Pumice (Abrasive)
- If you spill a product containing one of these chemicals on the surface, wipe up immediately, wash with soapy water, and rinse several times.